

## MOUNTING & MAINTENANCE INSTRUCTION

**Mirror for correctional facilities 700 x 500 mm stainless steel Super Mirror**

**Code: N08071**



### Mounting:

- Stainless steel mirrors are packed in cardboard packagings.
  - Before installing the mirror, make sure that the surface to be mounted is smooth and strong.
  - Before installing the mirror, remove it from the packaging. The packaging should be thrown away.
  - To install the mirror, purchase mounting kits (plugs + screws) or mounting glue or double-sided tape.
1. For mirrors with mounting holes - mirrors have 4 mounting holes with a diameter of 4 mm. To mount the mirror, make holes in the wall, peel off the protective film from the corners of the

mirror, then screw the mirror to the wall using screws.

Completely remove the protective film from the mirror, taking care not to damage the shiny surface.

2. For mirrors without mounting holes - glue the mirror with glue or double-sided tape from the side without the protective film in accordance with the appropriate instructions for use of the selected glue or double-sided tape. Then remove the protective film from the shiny surface of the mirror.

## Maintenance:

In order to maintain the smoothness and cleanliness of the surface of the products and to ensure that stainless steel products have a long service life, the following rules should be followed:

- Use of special cleaning and maintenance agents intended for stainless steel.
- Use of delicate microfiber cloths to clean the devices.
- Installation/use in rooms that do not contain an increased concentration of chlorine compounds, as well as bromides and iodides in the atmosphere.
- Quick removal of all deposits and dirt.
- Protect the surface of the products from any contact with carbon steel during transport and installation.
- Do not use powders, scouring pastes based on strong acids, alkalis containing chlorides, bromides, iodides, bleaches for washing and maintenance.
- Do not use dishwashing sponges and cloths with a hard material structure for washing and maintenance.

DYREKTOR HANDLOWY  
*Krzysztof Walczak*  
Krzysztof Walczak  
**faneco** Sp. z o.o. Sp. k.  
ul. Fredry 1/16, 61-701 Poznań  
NIP 778-13-42-896  
tel.: 61 6100213, 61 00124  
e-mail: info@faneco.com